


CRUISE CONTROL SYSTEM PARTS LOCATION



DIAGNOSIS SYSTEM

OUTPUT OF DIAGNOSTIC TROUBLE CODE

READ DIAGNOSTIC TROUBLE CODE


TYPE A

- (a) Turn the ignition switch on.
- (b) Turn the control switch to SET/COAST or RES/ACC position, and keep it there.
- (c) Push the main switch ON.
- (d) Check that the indicator light "CRUISE" light-up in the combination meter.
- (e) Turn the SET/COAST or RES/ACC switch off.
- (f) Meet the conditions listed in the table below.
- (g) Read the diagnosis trouble code on the cruise control indicator light.

No.	Conditions	Indication code	Diagnosis
1	Turn the control switch to SET/COAST position.		SET/COAST circuit is normal.
2	Turn the control switch to RES/ACC position.		RES/ACC circuit is normal.
3	Each cancel switch is turned ON. <ul style="list-style-type: none"> • Control switch (to CANCEL) • Stop light switch • Parking brake switch • Park/neutral position start switch (to N or P range) 		Each cancel switch is normal.
4	Drive at approx. 40 km/h (25 mph) or below.		No. 1 vehicle speed sensor circuit is normal.
	Drive at approx. 40 km/h (25 mph) or over (w/o ECT)		No. 1 vehicle speed sensor circuit is normal.

HINT:

- Indication codes appear in order from No.1.
- If there is no indication code, perform troubleshooting and inspection. (See page [BE-89](#) or [BE-103](#))
- Indication is stopped when the MAIN switch is repushed.



TYPE B








- (a) If while driving with the cruise control on, the system is canceled by a malfunction in either the actuator, speed sensor or speed control switch circuit, the cruise control indicator light "CRUISE" will blink 5 times.
- (b) While stopped, connect terminals 3 and 11 of the check connector.
HINT: If the ignition switch is turned off, the diagnostic code will be erased from the computer memory.
- (c) Read the diagnostic trouble code on the indicator light "CRUISE".

(w/Vacuum Type Actuator)

	Indication code	Diagnosis
	<p>0.25S 0.25S</p> <p>BE1939</p>	Normal.
11	<p>4S 1.5S 0.5S</p> <p>BE1940</p>	<ul style="list-style-type: none"> • Duty ratio of 100% output to acceleration side. • Overcurrent (short) in control valve circuit.
12	<p>1.5S 0.5S</p> <p>BE2711</p>	<ul style="list-style-type: none"> • Overcurrent (short) in reverse valve circuit. • Open in reverse valve circuit.
21	<p>BE1941</p>	Vehicle speed signal not sent for 140 m sec. or longer
23	<p>BE1943</p>	<ul style="list-style-type: none"> • Vehicle speed has decreased by 16 km/h (10 mph) or more from the set speed during cruising.
32	<p>BE1945</p>	Short circuit in control switch circuit.
34	<p>BE4342</p>	Control switch does not turn off before switching.
41	<p>BE4343</p>	ECU malfunction.

* If the set speed can be maintained when the speed control switch is again set at SET/COAST, there is no malfunction.

(w/ Motor Type Actuator)

Indication code		Diagnosis
	 <p>BE1939</p>	Normal.
11	 <p>BE1940</p>	Excessive current flowed to motor or magnet clutch drive circuit.
12	 <p>BE2711</p>	Open circuit in magnet clutch circuit
13	 <p>BE4344</p>	<ul style="list-style-type: none"> Position sensor circuit abnormal. Open circuit in motor.
21	 <p>BE1941</p>	Vehicle speed signal not sent for 140 msec. or longer
23	 <p>BE1943</p>	<ul style="list-style-type: none"> Vehicle speed has decreased by 16 km/h (10 mph) or more from the set speed during cruising.
31	 <p>BE1944</p>	RESUME/ACCEL switch is ON always when MAIN switch is pushed ON.
32	 <p>BE1945</p>	Short circuit in control switch circuit.
34	 <p>BE4342</p>	Control switch does not turn off before switching.
41	 <p>BE4345</p>	ECU malfunction.

* If the set speed can be maintained when the speed control switch is again set at SET/COAST, there is no malfunction.

HINT:

- Indication codes appear in order from No.11.
- If there is no indication code, perform troubleshooting and inspection. (See page BE-89 or 103)

TROUBLESHOOTING


w/Vacuum Type Actuator

You will find the source of the trouble more easily by properly using the table shown below. In this table, the numbers indicate the order of priority of the causes of trouble. Check each part in the order shown.

Chart No.			D	C	C	F	H, I	G	E	K	J			
Inspection Item			CC ECU	Actuator	Main Switch (in Control Switch)	Control Switch	Stop Light Switch	Clutch Switch or Park/ Neutral Position Switch	Parking Brake Switch	No. 1 Vehicle Speed Sensor, or Speedometer Cable	O/D OFF Circuit	Electrical Controlled Transaxle Solenoid No. 2 Circuit		
Diagnosis Trouble Code	Type B	Type A												
Problem														
<ul style="list-style-type: none"> • "CRUISE" indicator light blinks 5 times. • Cruise control system does not set. • Cruise control system does not operate. 	11		2	1										
	12		3	1			2							
	21		2							1				
	23		3	2						1				
	31		2			1								
	32		2			1								
	33		2			1								
	41		1											
Set speed deviates on high or low side.	Normal	4	OK	7	6	1	2	3	4	5				
			NG	2							1			
Set speed deviates on high or low side.	5	OK	2	1										
		NG									1			
Vehicle speed fluctuates when speed control switch turned to SET.			3	2						1				
Set speed does not cancel when brake pedal depressed.	3	OK	3	1			2							
		NG	2				1							
Set speed does not cancel when parking brake lever pulled.	3	OK	2	1										
		NG	2						1					
Set speed does not cancel when shifted to "N" range. (A/T)	3	OK	2	1										
		NG	2					1						
Set speed does not cancel when clutch pedal depressed. (M/T)	3	OK	2	1										
		NG	2					1						
Vehicle speed does not decrease when speed control switch turned to COAST.	1	OK	3	1						2				
		NG	2			1								
Vehicle speed does not accelerate when speed control switch turned to ACCEL.	2	OK		1						2	3	4		
		NG	2			1								
Vehicle speed does not return to memorized speed when control switch turned on RESUME	2	OK	3	1						2				
		NG	2			1								
Set speed does not cancel when speed control switch turned to CANCEL.	3	OK	2	1										
		NG	2			1								
Speed can be set below about 40 km/h (25 mph.)	4	OK	2	1										
		NG	2							1				
Cruise control will not disengage even at about 40 km/h (25 mph.)	4	OK	2	1										
		NG	2							1				
Acceleration response is sluggish when speed control switch turned to "ACCEL" or "RESUME".			5	2		1					3	4		

A POWER SOURCE CIRCUIT


HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.



CC: Cruise Control

B CRUISE CONTROL INDICATOR CIRCUIT

HINT: while carrying out the following inspection, make certain that the connectors and terminals are properly connected.



C CONTROL SWITCH CIRCUIT

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.

CONTROL SWITCH

Disconnect connector from control switch and inspect connector on wire harness side as follows.

INSPECT GROUND CONNECTION
Is there continuity between terminal 3 (B-17) and ground?

No

- Open circuit in wire harness between terminal 3(B-17) of control switch and ground.
- Ground faulty.

Yes

INSPECT CONTROL SWITCH (See page BE-120)
Is control switch operation normal?

No Replace control switch. Then recheck system.

Yes

CC ECU

Connect connector to control switch. Disconnect connector from CC ECU and inspect connectors on wire harness side as follows.

INSPECT MAIN SWITCH CIRCUIT
Is there no continuity between terminal 6 and ground with main switch OFF?

Yes Short circuit in wire harness between terminals 6 of CC ECU and (B-15) of control switch.

No

Is there continuity between terminal 6 and ground with main switch ON?

No Open circuit in wire harness between terminals 6 of CC ECU and 5 (B-15) of control switch.

Yes

INSPECT CONTROL SWITCH CIRCUIT
Is there no continuity between terminal 19 and ground with control switch OFF?

Yes Short circuit in wire harness between terminals 19 of CC ECU and 4 (B-5) of control switch.

No

Is there resistance as shown in table below between terminal 19 and ground when control switch is turned to each position?

Position	Resistance (Ω)
RES/ACC	Approx. 68
SET/COAST	Approx. 198
CANCEL	Approx. 418

No Open circuit in wire harness between terminals 19 of CC ECU and 4 (B-5) of control switch.

Yes

Replace CC ECU. Then recheck system.

() : without SRS
CC: Cruise Control

D ACTUATOR CIRCUIT

HINT: while carrying out the following inspection, make certain that the connectors and terminals are properly connected.

VACUUM HOSE

Are there cracks or other damage on vacuum hose? Yes → Replace hose. Then recheck system.

ACTUATOR

Disconnect connector from actuator and inspect connector on wire harness side as follows.

CC ECU

INSPECT GROUND CONNECTION
Is there continuity between terminal 3 and ground?

No → Disconnect connector from CC ECU and inspect connector on wire harness side as follows.

Is there continuity between terminal 15 and ground?

No →

- Open circuit in wire harness between terminal 15 of CC ECU and ground.
- Ground faulty.

INSPECT CC ECU
Is there continuity between terminals 15 and 16 on ECU side connector?

No → Replace CC ECU. Then recheck system.


Open circuit in wire harness between terminals 16 or CC ECU and 3 of actuator.

INSPECT ACTUATOR (See page BE-121)
Is actuator operation normal?

No → Replace actuator. Then recheck system.

CC: Cruise Control

CONTINUED ON NEXT PAGE




CC: Cruise Control

E-1 NO. 1 VEHICLE SPEED SENSOR CIRCUIT (with A/T)

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.

SPEED METER CABLE




CC: Cruise Control

E-2 NO. 1 VEHICLE SPEED SENSOR CIRCUIT (with M/T)

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.


NO. 1 VEHICLE SPEED SENSOR




CC: Cruise Control

F STOP LIGHT SWITCH CIRCUIT

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.






CC: Cruise Control

G PARKING BRAKE SWITCH CIRCUIT


HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.



CC: Cruise Control

H PARK/NEUTRAL POSITION SWITCH (with A/T)

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.




CC: Cruise Control

CLUTCH SWITCH CIRCUIT (with M/T)


HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.

CLUTCH SWITCH



J ELECTRICAL CONTROLLED TRANSAXLE SOLENOID NO.2 CIRCUIT (with ECT1)


HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.



CC: Cruise Control

K O/D OFF CIRCUIT (with A/T)

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.



CC: Cruise Control


w/Motor Type Actuator

You will find the source of the trouble more easily by properly using the table shown below. In this table, the numbers indicate the order of priority of the causes of trouble. Check each part in the order shown.

Chart No.				D	C	C	F	H,I	G	E	K	J	L	
Inspection Item				Actuator	Main Switch tin Control Switch)	Control Switch	Stop Light Switch	Clutch Switch or Park/ Neutral Position Switch	Parking Brake Switch	No. 1 Vehicle Speed Sensor, or Speedometer Cable	O/D OFF Circuit	Electrical Controlled Trans, axle Solenoid No.2 Circuit	Throttle Position Sensor (IDU)	
Diagnosis Code	Type B	Type A	CC ECU											
Problem														
<ul style="list-style-type: none"> • "CRUISE" Indicator light blinks 5 times. • Cruise control system does not set. • Cruise control system does not operate. 	11		2	1										
	12		3	1			2							
	21		2											
	23			2						1			3	
	31		2			1								
	32		2			1								
	33		2			1								
	41		1											
Set speed deviates on high or low side.	Normal	4	OK	7	6	1	2	3	4	5				
		NG	2							1				
Set speed deviates on high or low side.	5	OK	3	1									2	
		NG								1				
Vehicle speed fluctuates when speed control switch turned to SET.			3	2						1				
Set speed does not cancel when brake pedal depressed.	3	OK	3	1			2							
		NG	2				1							
Set speed does not cancel when parking brake lever pulled.	3	OK	2	1										
		NG	2						1					
Set speed does not cancel when shifted to "N" range. (A/T)	3	OK	2	1					1					
		NG	2											
Set speed does not cancel when clutch pedal depressed. (M/T)	3	OK	2	1					1					
		NG	2											
Vehicle speed does not decrease when speed control switch turned to COAST.	1	OK	3	1						2				
		NG	2				1							
Vehicle speed does not accelerate when speed control switch turned to ACCEL.	2	OK		1						2	3	4		
		NG	2				1							
Vehicle speed does not return to memorized speed when control switch turned on RESUME	2	OK	3	1						2				
		NG	2				1							
Set speed does not cancel when speed control switch turned to CANCEL.	3	OK	2	1										
		NG	2				1							
Speed can be set below about 40 km/h (25 mph.)	4	OK	2	1										
		NG	2							1				
Cruise control will not disengage even at about 40 km/h (25 mph.)	4	OK	2	1										
		NG	2							1				
Acceleration response is sluggish when speed control switch turned to "ACCEL" or "RESUME".			6	2			1				3	4	5	

A POWER SOURCE CIRCUIT


HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.



CC: Cruise Control

B CRUISE CONTROL INDICATOR CIRCUIT

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.




CC: Cruise Control


C CONTROL SWITCH CIRCUIT

HINT: while carrying out the following inspection, make certain that the connectors and terminals are properly connected.

CONTROL SWITCH



CC ECU




() : without SRS
CC: Cruise Control


D ACTUATOR CIRCUIT

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.

ACTUATOR



CC: Cruise Control




CC: Cruise Control

E-1 NO. 1 VEHICLE SPEED SENSOR CIRCUIT (with A/T)

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.

SPEED METER CABLE



COMBINATION METER

Disconnect connector "B" from combination meter and inspect connector on wire harness side as follows.

INSPECT GROUND CONNECTION
Is there continuity between terminal B-5 and ground?

- No →
- Open circuit in wire harness between terminal B-5 of combination meter and ground.
 - Ground faulty.

INSPECT NO. 1 VEHICLE SPEED SENSOR (See page BE-121)
Is speed sensor operation normal?

No → Replace speedometer. Then recheck system.

CC ECU

Connect connector "B" to combination meter. Disconnect connector "A" from CC ECU and inspect connector on wire harness side as follows.

INSPECT NO. 1 VEHICLE SPEED SENSOR CIRCUIT
Is there continuity repeatedly between terminal A-7 and ground?

- No →
- Open or short circuit in wire harness between terminals A-7 of CC ECU and B-6 of combination meter.
 - Open or short circuit in circuit plate of combination meter between terminal B-6 and speed sensor.
 - Open circuit in circuit plate of combination meter between terminal B-5 and speed sensor.


Yes → Replace CC ECU. Then recheck system.

CC: Cruise Control

E-2 NO. 1 VEHICLE SPEED SENSOR CIRCUIT (with M/T)

HINT: While carrying out the following inspection, make certain that the connectors and terminal are properly connected.


NO. 1 VEHICLE SPEED SENSOR




CC: Cruise Control

F STOP LIGHT SWITCH CIRCUIT

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.






CC: Cruise Control

G PARKING BRAKE SWITCH CIRCUIT


HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.



CC: Cruise Control

H PARK/NEUTRAL POSITION SWITCH CIRCUIT (with A/T)

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.




CC: Cruise Control


I CLUTCH SWITCH CIRCUIT (with M/T)

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.

CLUTCH SWITCH




CC ECU



CC: Cruise Control


J ELECTRICAL CONTROLLED TRANSAXLE SOLENOID No2 CIRCUIT (with ECT)

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.



K O/D OFF CIRCUIT (with A/T)

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.



L IDL SIGNAL CIRCUIT

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.

THROTTLE POSITION SENSOR

INSPECT THROTTLE POSITION SENSOR ADJUSTMENT (See page FI-116, 121 or 124)
Is throttle position sensor adjustment normal?

No → Adjust position sensor position. Then recheck system.

Yes

INSPECT THROTTLE POSITION SENSOR (See page FI-113, 118 or 123)
Is throttle position sensor operation normal?

No → Replace throttle position sensor. Then recheck system.

Yes

CC ECU

Connect connector to throttle position sensor. Disconnect connector "B" from CC ECU and inspect connector on wire harness side as follows.

INSPECT IDL SIGNAL CIRCUIT
Is there continuity between terminal B-9 and ground when acceleration pedal is released?

No → Open circuit in wire harness between terminals B-9 of CC ECU and 2 (1) of throttle position sensor.

Yes

Is there no continuity between terminal 13-9 and ground when acceleration pedal is depressed?


No → Short circuit wire harness between terminals B-9 of CC ECU and 2 (1) of throttle position sensor.

Yes

Replace CC ECU. Then recheck system.

(): 3-Pin Type Throttle Position Sensor Connector
CC: Cruise Control

Wire Harness Side



e-20-2-C

CRUISE CONTROL ECU


CRUISE CONTROL ECU INSPECTION

ECU CIRCUIT


Disconnect connector and inspect connector on wire harness side as shown in the chart.

(with Vacuum Type Actuator)


Check for	Measured item	Tester connection	Condition		Specified Valve
Continuity	DLC2 circuit	1 – ground	Constant		No continuity
			Terminal Tc and E1 connected		Continuity
	Control switch (main switch)	6 – ground	Main switch position	OFF	No continuity
				ON	Continuity
	Engine Coolant temp. switch and O/D main switch	7 – ground	Engine coolant is Cold		Continuity
			Engine coolant is Hot		
			O/D main switch position	OFF	No continuity
	OF	Continuity			
	Park/neutral position switch (A/T)	13 – ground	Shift lever position	N or P	Continuity
				L,2DorR	No continuity
Clutch switch (M/T)	13 – ground	Clutch pedal position	released	No continuity	
			depressed	Continuity	
Parking brake switch	14 – ground	Parking brake lever position	released	No continuity	
			pulled	Continuity	
Ground connection	15 – ground	Constant		Continuity	
Resistance	Actuator (release valve)	3 – 16	Brake pedal position	released	Approx. 68 Ω
				depressed	No continuity
	Actuator (control valve)	5 – 16	Constant		Approx. 30Ω
	Electrical controlled transaxle No.2 solenoid valve	9 – ground	Constant		Approx. 13Ω
	Control switch	19 – ground	Control switch position	OFF	No continuity
RES/ACC				Approx. 68 Ω	
SET/COAST				Approx. 198 Ω	
CANCEL				Approx. 418 Ω	
Voltage	CC indicator	4 – ground	Ignition switch position	LOCK or ACC	No voltage
				ON	Battery positive voltage
	No. 1 vehicle speed sensor	8 – ground	With ignition switch on, speedometer shaft or No. 1 vehicle speed sensor shaft turned.		Voltage changes repeatedly
	Power source	12 – ground	Ignition switch position	LOCK or ACC	No voltage
				ON	Battery positive voltage
	Stop light	17 – ground	Brake pedal position	released	No voltage
depressed				Battery positive voltage	
STOP fuse	18 – ground	Constant		Battery positive voltage	

**Wire Harness Side
Connector "B"**


e-10-2-C e-12-2-B

Connector "A"

(with Motor Type Actuator)

Check for	Measured item	Tester connection	Condition		Specified Valve
Continuity	Park/neutral position start switch (A/T)	A-4 - ground	Shift lever- position	Nor P	Continuity
				L, 2, D or R	No continuity
	Clutch switch (M/T)	A-4 - ground	Clutch pedal position	released	No continuity
				depressed	Continuity
	Parking brake switch	A-5 - ground	Parking brake lever position	released	No continuity
				pulled	Continuity
	Control switch	A-8 - ground	Main switch position	OFF	No continuity
				ON	Continuity
	Ground connection	A-9 - ground	Constant		Continuity
	Engine coolant temp. switch and O/D main switch	B-2 - ground	Engine coolant temp. is Cold		Continuity
			Engine coolant temp. is Hot		
			O/D main switch position	OFF	No continuity
	ON	Continuity			
Actuator (motor)	B-4 - B-10	Actuator arm position	max. OPEN	(B-4 → B-10) Continuity	
			max. CLOSE	(B-10 → B-4) Continuity	
			any position except above position	(B-4 → B-10) Continuity	
DLC2 circuit	B-7 - ground	Constant		Continuity	
		Terminals Tc and E1 connected		Continuity	
Throttle position sensor (IDL)	B-9 - ground	Acceleration pedal position	released	Continuity	
			depressed	No continuity	
Resistance	Actuator (position sensor)	A-10 - A-12	Constant		Approx. 2 kΩ
		A-10-A-11	Actuator arm turned		Resistance change even
	Electrical controlled transaxle No.2 solenoid valve	B-1 - ground	Constant		Approx. 13Ω
	Actuator (magnet clutch)	B-3 - ground	Brake pedal position	released	Approx. 38.5Ω
				depressed	No continuity
	Control switch	B-8 - ground	Control switch position	OFF	No continuity
RES/ACC				Approx. 68 92	
SE ₁ COAST				Approx. 198 Ω	
CANCEL				Approx. 418 Ω	
Voltage	Power source	A-1 -ground	Ignition switch position	LOCK or ACC	No voltage
				ON	Battery positive voltage
	STOP fuse	A-2 - ground	Constant		Battery positive voltage
	Stop light	A-3 - ground	Brake pedal position	released	No voltage
				depressed	Battery positive voltage
No. 1 vehicle speed sensor	A-7 - ground	With ignition switch ON, speedometer shaft or No. 1 vehicle speed sensor shaft turned.		Voltage changes repeatedly	



CRUISE CONTROL SWITCH

CRUISE CONTROL SWITCH INSPECTION

(a) Check continuity between terminals 3 (B-17) and 5 (B-15)

Main switch position	Condition
OFF	No continuity
ON	Continuity

(b) Measure resistance between terminals 3 (B-17) and 4 (B-5)

Control switch position	Resistance (Ω)
OFF	∞ (No continuity)
RES/ACC	Approx. 68
SET/COAST	Approx. 198
CANCEL	Approx. 418

If resistance value is not as specified, replace the control switch.

STOP LIGHT SWITCH

STOP LIGHT SWITCH INSPECTION CONTINUITY

Terminal	1	2	3	4
Switch position				
Switch pin free (Brake pedal depressed)	○	—	○	
Switch pin pushed in (Brake pedal released)		○	—	○

If continuity is not as specified, replace the stop light switch.

CLUTCH SWITCH

CLUTCH SWITCH INSPECTION

M/T/CONTINUITY

 <p>BE2737 G-2-2</p>	Terminal	1	2
	Condition		
	Switch pin free (Clutch pedal depressed)	○	○
Switch pin pushed in (Clutch pedal released)			

If continuity is not as specified, replace the switch.

PARK/NEUTRAL POSITION SWITCH


A/T

ECT: See page [AT-29](#)

w/o ECT: See page [AT-33](#)

PARKING BRAKE SWITCH

See page [BE-56](#).



NO. 1 VEHICLE SPEED SENSOR

NO. 1 VEHICLE SPEED SENSOR INSPECTION


M/T

- Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 3.
- Connect the positive (+) lead from the voltmeter to terminal 2 and the negative (-) lead to the battery negative (-) terminal.
- Check that the voltmeter indicates approx. 5 volts four times per each revolution of the shaft.

If operation is not as specified, replace the speed sensor.

A/T

See page [BE-50](#).



ACTUATOR


ACTUATOR INSPECTION

VACUUM TYPE

- Measure the resistance between terminals as follows.

Resistance: 1 - 3 Approx. 68Ω

2 - 3 Approx. 30 Ω




- (b) Connect the positive (+) lead from the battery to terminals 1 and 2, and the negative (-) lead to terminal 3.
- (c) Slowly apply vacuum from 0 to 300 mmHg (0 to 11.81 in.Hg, 0 to 40.0 kPa), check that the control cable can be pulled smoothly.


Cable stroke: Approx. 40 mm (1.57 in.)

- (d) With the vacuum stabilized, check that the control cable does not return.

HINT: As you apply and hold the vacuum with the vacuum pump, the drawn-in diaphragm will in some cases return. This does not indicate a malfunction. Actuator leakage is allowable.




- (e) Disconnect terminal 1 or 2 and check that the control cable returns to its original position and the vacuum returns to 0 mmHg (0 in.Hg, 0 kPa). If operation is not as specified, replace the actuator.




MOTOR TYPE MAGNET CLUTCH

- (a) Check that the arm moves smoothly by hand.




- (b) Connect the positive (+) lead from the battery to terminal 5 and the negative (-) lead to terminal 4. (Magnet clutch turned ON)
- (c) Check that the arm does not move by hand. If operation is not as specified, replace the motor.

**MOTOR**


(a) With the magnet clutch ON, connect the positive W lead from the battery to terminal 6 and the negative (-) lead to terminal 7, check that the arm moves to the open side.

(b) When the arm reached to the open position, check that the motor operation stops.




(c) With the magnet clutch ON, connect the positive (+) lead from the battery to terminal 7 and the negative (-) lead to terminal 6, check that the arm moves to the close side.

(d) When the arm reaches to the closed position, check that the motor operation stops.

**POSITION SENSOR**

(a) Measure the resistance between terminals 1 and 3.

Resistance: Approx. 2 k Ω



(b) When the arm is moving from the closed to open position, check that resistance between terminals 2 and 3 increases from approx. 0.5 to 1.7 k Ω .

If operation is not as specified, replace the motor.