



BACK-UP LIGHT SYSTEM PARTS LOCATION



Back-Up Light Switch

Back-Up Light




Junction Block No.1
• GAUGE Fuse

TROUBLESHOOTING

The table below will be useful for you in troubleshooting these electrical problems. The most likely causes of the malfunction are shown in the order of their probability. Inspect each part in the order shown, and replace the part when it is found to be faulty.

Trouble	Parts name	See page
Back-up light does not light up.	1. GAUGE Fuse 2. Ignition Switch 3. Back-Up Light Switch 4. Park/Neutral Position Switch 5. Wire Harness 6. Bulb	BE-3 BE-11 BE-39 AT-30 — —
Back-up light remains always on.	1. Wire Harness	—
Only one light does not light up.	1. Wire Harness 2. Bulb	— —



BACK-UP LIGHT SWITCH BACK-UP LIGHT SWITCH INSPECTION CONTINUITY

Switch Position	Specified
Push	Continuity
Free	No continuity

If operation is not as specified, replace the switch.

PARK/NEUTRAL POSITION SWITCH

See page [AT-30](#).