





Electronic Control System (A243L 4A-FE) ELECTRONIC CONTROL CIRCUIT



ELECTRONIC CONTROL COMPONENTS





INSPECTION OF ELECTRONIC CONTROL COMPONENTS

1. INSPECT O/D SOLENOID


- (a) Disconnect the solenoid connector.
- (b) Apply voltage between terminals 1 and 2.
At this time, confirm that a solenoid operation sound is heard.
- (c) Using an ohmmeter, measure the solenoid coil resistance between terminals 1 and 2.
Resistance: 11 – 15Ω
- (d) Connect the solenoid connector.

2. INSPECT O/D MAIN SWITCH

(See page [AT-30](#))

3. INSPECT O/D OFF INDICATOR LIGHT

(See page [AT-12](#))



4. INSPECT PARK/NEUTRAL POSITION SWITCH

Using an ohmmeter, check the continuity of the terminals for each switch position shown in the table below.

Terminal / Position	RB	RL	N	B
P			○—○	○—○
R	○—○			
N			○—○	○—○