



SEAT BELTS COMPONENTS



N·m (kgf·cm, ft·lbf) : Specified torque




SEAT BELT

[Emergency Locking Retractor (ELR) [TYPE]

1. RUNNING TEST (IN SAFE AREA)

- (a) Fasten the seat belt.
- (b) Drive the car at 16 km/h (10 mph) and make a very hard stop.
- (c) Check that the belt is locked and cannot be extended at this time.

HINT: Conduct this test in a safe area. If the belt does not lock, remove the belt mechanism assembly and conduct the following static check. Also, whenever installing a new belt assembly, verify proper operation before installation.



2. STATIC TEST

- (a) Remove the locking retractor assembly.
- (b) Tilt the retractor slowly.
- (c) Verify that the belt can be pulled out at a tilt of 15 degrees or less, and cannot be pulled out at over 45 degrees of tilt.

If problem is found, replace the assembly.