


POWER TRANSISTOR (with AUTO A/C) **INSPECTION OF POWER TRANSISTOR INSPECT POWER TRANSISTOR**

- (a) Connect the positive (+) leads from the battery to terminal 1 through a 3.4 W test bulb and terminal 3 of a 120Ω resistor.
- (b) Connect the negative (-) lead from the battery to terminal 2, then check that the test bulb lights up. If operation is not as specified, replace the power transistor.


BLOWER RESISTOR INSPECTION OF BLOWER RESISTOR

INSPECT BLOWER RESISTOR CONTINUITY

(with AUTO A/C: Dial Type Blower Speed Control Switch)



(without AUTO A/C)



If continuity is not as specified, replace the blower resistor.