

# BACK DOOR GLASS PREPARE ITEMS LISTED


(See page BO-32)





# REMOVAL OF BACK DOOR GLASS


- 1. REMOVE WIPER ARM
- 2. DISCONNECT DEFOGGER WIRE CONNECTORS
- 3. REMOVE HIGH MOUNT STOP LIGHT AND COVER
  - (a) Using a screwdriver, remove the clips.
  - (b) Remove four bolts and the light.
  - (c) Disconnect the connector.



### 4. REMOVE BACK DOOR SIDE TRIM


Using a screwdriver, pry loose the clips to remove the trim.

HINT: Tape the screwdriver tip before use.



#### 5. REMOVE BACK DOOR UPPER TRIM


- (a) Remove two screws and two clips.
- (b) Using the screwdriver, pry loose the clips to remove the trim.



### 6. REMOVE BACK DOOR TRIM

Using the screwdriver, pry loose the clips to remove the trim.

7. REMOVE BACK DOOR MOULDING (See page BO-31)



#### 8. REMOVE BACK DOOR GLASS

- (a) Remove four nuts.
- (b) Remove the glass in the same manner as the wind-shield glass.

NOTICE: Do not damage the retainers as shown with the piano wire.

# INSTALLATION OF BACK DOOR GLASS

(See page BO-48)

- 1. CLEAN AND SHAPE CONTACT SURFACE OF BODY (See step 1 on page BO-34)
- 2. CLEAN REMOVED GLASS BEFORE INSTALLATION (See step 2 on page BO-35)
- 3. POSITION GLASS (See step 3 on page BO-35)
- 4. CLEAN CONTACT SURFACE OF GLASS (See step 4 on page BO-35)
- 5. COAT CONTACT SURFACE OF BODY WITH PRIMER "M" (See step 6 on page BO-35)
- 6. COAT CONTACT SURFACE OF GLASS WITH PRIMER "G" (See step 7 on page BO-36)
- 7. MIX ADHESIVE COATING (See step 8 on page BO-36)
- 8. APPLY ADHESIVE (See step 9 on page BO-36)
- 9. INSTALL GLASS (See step 10 on page BO-36)
  HINT: Align the bolts of retainer with the body holes, then install the glass with four nuts.

### 10. INSTALL BACK DOOR MOULDING

(See page BO-31)

HINT: Before the glass adhesive is hardened, install the moulding.

## 11. INSPECT FOR LEAKS AND REPAIR

(See step 11 on page BO-37)

### 12. INSTALL FOLLOWING PARTS:

- (a) Back door trim
- (b) Back door upper trim
- (c) Back door side trim
- (d) High mount stop light and cover
- (e) Wiper arm

### 13. CONNECT DEFOGGER WIRE CONNECTORS