

BO-23

Body Outside Moulding COMPONENTS





Roof Drip Moulding

1. REMOVE ROOF SIDE WEATHERSTRIP

- (a) Using a clip remover, remove four clips from th weatherstrip.
- (b) Remove the weatherstrip from the end with your hand.
- 2. REMOVE ROOF SIDE WEATHERSTRIP REAR RETAINER

Remove three screws and the retainer.


3. REMOVE ROOF DRIP SIDE FINISH FRONT MOULDING


Remove ten screws and the moulding.

INSTALLATION

- 1. **INSTALL ROOF DRIP SIDE FINISH FRONT MOULDING** Install ten screws and the moulding.
- 2. INSTALL ROOF SIDE WEATHERSTRIP REAR RETAINER

Install three screws and the retainer.





- 3. INSTALL ROOF SIDE WEATHERSTRIP
 - (a) Install the weatherstrip to the moulding as shown.(b) Install four clips.

Front Door Belt Moulding REMOVAL

- 1. REMOVE FRONT DOOR COMPONENT PARTS: See steps 1, 2, 3, 5 and 6 on pages BO-6 to 8)
- 2. REMOVE FRONT DOOR BELT MOULDIN: See step 9 on page BO-9)

INSTALLATION

- 1. INSTALL FRONT DOOR BELT MOULDIN: See step 9 on page BO-14)
- 2. INSTALL FRONT DOOR COMPONENT PARTS: See steps 10, 12 and 18 on pages BO-14 and 17)

Quarter– Window Glass with Moulding REMOVAL

Liftback: (See steps 1 to 9 on pages BO-39 to 40) Coupe: (See steps 1 to 7 on pages BO-42 to 43)


INSTALLATION

Liftback: (See steps 1 to 3 on pages BO-40 to 41 Coupe: (See steps 1 to 7 on pages BO-43 to 44)

Front Fender Mud Guard REMOVAL AND INSTALLATION

1. REMOVE MUD GUARD

- (a) Remove the screw.
- (b) Using a screwdriver, pry loose clips and remove the mud guard.
- 2. INSTALL MUD GUARD
 - (a) Install the mud guard onto the body.
 - (b) Install the screw.



Side Mud Guard REMOVAL AND INSTALLATION

1. REMOVE MUD GUARD

- (a) Remove three screws.
- (b) Using a clip remover, pry loose the clips to remove the mud guard.

2. INSTALL MUD GUARD

- (a) Align the clips of the guard with the grommet, then install the guard.
- (b) Install three screws.