










PREPARATION

SST (SPECIAL SERVICE TOOLS)


MX025-01

 <p>09308-00010 Oil Seal Puller</p>	<p>Input shaft front bearing Output shaft front bearing</p>
 <p>09309-12020 5th Driven Gear Replacer</p>	
 <p>09310-17010 Transaxle Gear Remover & Replacer</p>	
 <p>(09310-07010) Plate</p>	
 <p>(09310-07020) Center Bolt</p>	
 <p>(09310-07030) Set Bolt</p>	
 <p>09310-35010 Countershaft Bearing Replacer</p>	<p>Input shaft front bearing Output shaft front bearing</p>
 <p>09316-60010 Transmission & Transfer Bearing Replacer</p>	
 <p>(09316-00010) Replacer Pipe</p>	
 <p>(09316-00040) Replacer "C"</p>	
 <p>09350-32014 TOYOTA Automatic Transmission Tool Set</p>	
 <p>(09351-32120) Overdrive Bearing Replacer</p>	<p>Differential side bearing</p>
 <p>(09351-32130) Handle</p>	

	<p>(09351-32150) Oil Seal Replacer Differential side bearing Oil seal (Transaxle case side)</p>	
	<p>09502-10012 Differential Side Bearing Puller</p>	
	<p>09564-32011 Differential Preload Adaptor</p>	
	<p>09608-12010 Front Hub & Drive Pinion Bearing Replacer Set</p>	
	<p>(09608-00070) Drive Pinion Rear Bearing Cone Replacer</p>	<p>Input shaft rear bearing 4th drive gear and rear bearing</p>
	<p>09608-20012 Front Hub & Drive Pinion Bearing Tool Set</p>	
	<p>(09608-00080) Replacer</p>	<p>Input shaft front oil seal Control shaft cover oil seal</p>
	<p>(09808-03020) Handle</p>	
	<p>(09608-03060) Replacer</p>	<p>Differential taper roller bearing outer race</p>
	<p>09612-22011 Tilt Handle Bearing Replacer</p>	<p>Output shaft rear bearing No.3 clutch hub</p>
	<p>09950-00020 Bearing Remover</p>	
	<p>09950-20017 Universal Puller</p>	

RECOMMENDED TOOLS

MX026-01

	09025-00010 Small Torque Wrench	Differential preload
	09031-00030 Pin Punch	
	09905-00012 Snap Ring No. 1 Expander	

EQUIPMENT

MX027-01

Dial indicator	
Torque wrench	
Feeler gauge	

LUBRICANT

MX028-01

Item	Capacity	Classification
Manual transaxle oil	2.6 liters (2.7 US qts, 2.3 Imp.qts)	API GL-3, GL-4 or GL-5 SAE 75W-90

SSM (SPECIAL SERVICE MATERIALS)

MX029-01

	08826-00090 Seal Packing 1281, Three bond 1281 or equivalent	Transmission case x Transaxle case Transmission case x Case cover
	08833-00080 Adhesive 1344, THREE BOND 1344, LOCTITE 242 or equivalent	Straight screw plug Control shaft cover bolt